

800-428-8560 midwesthomes4pets.com P.O. Box 1031 Muncie, Indiana 47308



Assembly Instructions for Model Number 158XL

IMPORTANT INFORMATION

Unwrap and remove all parts from the box. Keep the box and packing material until the product is assembled. In case of return or exchange, failure to return product in similar condition as received could result in limited reimbursement. Please save sales receipt as proof of purchase for warranty purposes. Check to ensure you have all the parts below. If you discover any parts are missing, immediately call our toll-free service helpline at 1-800-428-8560 (Monday - Friday 9 a.m. to 4 p.m. EST) or at info@midwesthomes4pets.com.

PARTS IDENTIFICATION

- A Plastic Bottom
- B Plastic Sides 2
- C Plastic Ends 2
- D Wire Top with Door
- E Side Panel/Door 2
- F Corner Stabilizer 2
- G Corner Cap 4
- H Clip 8
- I Water Bottle
- J Hay Feeder
- K Elevated Feeding Platform
- L Food Bowl



ASSEMBLY INSTRUCTIONS

1. Assemble the plastic base. Connect the two Plastic Sides (B) to the Plastic Bottom (A). Each side piece has L-shaped tabs that align with the holes in the lip of the Plastic Bottom. Once inserted, slide the entire side piece until it clicks into place.



 Attach the two Plastic Ends (C). They have V-shaped notches that slide onto the ends of the Plastic Sides (B). The Plastic Ends also have three tabs on the bottom that will connect with the holes in Plastic Bottom (A). Push downward until the ends click into place.



3. Lay out the Wire Top with Door (D) so the door is on the floor. When positioned correctly, the loop will be UNDER the horizontal wires and the prongs of the door latches will protrude UP toward the ceiling. Bring the front, back, and sides together. Secure with two Corner Stabilizers (F) in the back, as shown.



4. Attach the Side Panels/Doors (E) to the Wire Top. Place a Corner Cap (G) on each corner of the panels as shown.



5. Place the eight Clips (H) around the outside of the Wire Top as shown. The hooks of each clip will hang on the third horizontal wire from the bottom. We recommend two clips in the back, one on each side, and two on each white door panel. Each clip should straddle a vertical wire so they do not shift side-to-side. When fully assembled, the clips will be used to secure the Wire Top to the Plastic Bottom.



6. Connect the two pieces of the Elevated Feeding Platform (K). Place the Bowl (L) over the stabilizing ring on the platform.



 Place the Elevated Feeding Platform and Wire Top on the Plastic Bottom. The Corner Stabilizers (F) will click into the corners of the base, while the Clips (H) will secure the Wire Top to the Plastic Bottom on all sides.



8. Attach the Hay Feeder (J) on the outside of the home in the desired location. The Water Bottle (I) can be mounted from the outside or the inside of the home according to your preference. Furnish with bedding, toys, and accessories as desired.



To clean your Wabbitat Deluxe Rabbit Home, wipe with a damp cloth and mild, pet-safe cleaner. Allow to air dry. Do not expose to direct sunlight for extended periods of time.

TOLL-FREE SERVICE HELPLINE: If you have any problems or questions with the assembly of your Wabbitat Deluxe Rabbit Home, call our Service Helpline at: 1-800-428-8560 between 9:00 a.m. and 4:00 p.m. (EST) Monday through Friday.

LIMITED MANUFACTURER'S WARRANTY

- 1. For one (1) year from the date of original purchase, MIDWEST Homes For Pets ("MIDWEST") warrants to the purchaser of this pet home that, should it prove defective by reason of improper workmanship and/or material, MIDWEST will repair or replace, at its option, any defective part of the pet home, without charge for the part or for shipping. Replacement parts are warranted for the remainder of the original period.
- 2. THIS WARRANTY DOES NOT COVER defects in the home caused by any animal, any physical abuse to or misuse of the pet home, any damage caused by the original purchaser or any third party, or any defects arising or discovered more than one (1) year from the original retail purchase date.

3. STEPS TO OBTAIN WARRANTY SERVICE:

A. The purchaser must call MIDWEST's HELPLINE, 800-428-8560, to report the alleged defect to a customer service representative or obtain missing parts.

B. The customer service representative will determine if the defect is covered by this warranty and, if it is, will authorize and instruct the purchaser in how to obtain corrective action.

C. MIDWEST may require the purchaser to present the sales receipt or other proof of purchase prior to authorizing any return or replacement. No returns or replacements will be permitted without proper authorization. If a return or replacement is authorized, you may be requested to return the item to MIDWEST or to make the item available for pick-up by MIDWEST.

- 4. ANY EXPRESS WARRANTY NOT PROVIDED IN THIS WARRANTY DOCUMENT, AND ANY REMEDY FOR BREACH OF CONTRACT THAT, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION OR OPERATION OF LAW, IS HEREBY EXCLUDED AND DISCLAIMED. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO A TERM OF ONE (1) YEAR. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.
- 5. UNDER NO CIRCUMSTANCES SHALL MIDWEST BE LIABLE TO PURCHASER OR ANY OTHER PERSON FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER ARISING OUT OF BREACH OF WARRANTY, BREACH OF CONTRACT OR OTHERWISE, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATIONS OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU.
- 6. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For a Complete Listing of Products

Small Animal Habitats • Pet Beds Outdoor Hutches & Coops • Pet Playpens.



- Come Visit Our Website midwesthomes4pets.com